



DEPARTURE PROCEDURE

Departure Procedure

- Rwy 10 – ½:** NO LEFT turn below **1300**.
Note: Road to 766 ASL aprx 900' past departure end of rwy. Trees to 801 ASL aprx 450' past departure end of rwy, 400' LEFT of rwy centreline. Trees to 801 ASL aprx 1000' past departure end of rwy, 250' RIGHT of rwy centreline.
- Rwy 14 – ½:** NO RIGHT turn below **1300**.
Note: Road to 766 ASL aprx 450' past departure end of rwy, both LEFT and RIGHT of rwy centreline. Trees to 801 ASL aprx 0.2 NM past departure end of rwy, both LEFT and RIGHT of rwy centreline.
- Rwy 28 – ½:**
Note: Buildings to 749 ASL abeam departure end of rwy, 450' LEFT of rwy centreline. Trees to 769 ASL aprx 800' past departure end of rwy, 400' RIGHT of rwy centreline. Trees to 769 ASL aprx 0.2 NM past departure end of rwy, both LEFT and RIGHT of rwy centreline.
- Rwy 32 – ½:**
Note: Trees to 713 ASL abeam departure end of rwy, both LEFT and RIGHT of rwy centreline.

Source of Canadian Civil Aeronautical Data: © 2026 NAV CANADA All rights reserved

