

NOISE ABATEMENT PROCEDURES

Propeller Driven Aircraft

Departure Procedures

Rwy 32 – Climb on runway heading to **1500'** before proceeding on course.

Arrival Procedures – VFR

Circuit height **1500'**. Right hand circuits for rwys 07, 14 and 22 (weather permitting).
Rwys 04, 14 – Maintain **1500'** until established on final approach (weather permitting).

Training Flights

- 1. Permitted from 0815 – 2359 hours local time.
- 2. No VFR training circuits on rwys 14 or 32 below **1500'**.
- 3. No practice circling procedures to rwy 14.

Source of Canadian Civil Aeronautical Data: © 2026 NAV CANADA All rights reserved