

NOISE ABATEMENT PROCEDURES

Runway	Noise Abatement Procedures
35L	No left turns below 6500' . No right turns beyond hdg 015 below 6500' .
35R	No left turns beyond hdg 315 or no right turns beyond hdg 360 below 6500' .

It is the pilot's responsibility to adhere to published Noise Abatement Procedures.

Arrival Procedures – Visual Approach

Clearance for approach or for landing does not cancel the arrival procedures described below. Pilots are requested to use delayed gear and flap extension and low power/drag configurations consistent with operating procedures and safety.

Runway	Noise Abatement Procedures
All rwys	Military jet aircraft multiple circuits and all overhead breaks prohibited.
11	Join final approach at or above the PAPI glide path slope.
29, 35L, 35R, 17R and 17L	Intercept final approach at or above 4800' ASL and prior to the FAF or FAWP for the rwy in use.

Source of Canadian Civil Aeronautical Data: © 2026 NAV CANADA All rights reserved