

Departure Route Description

Rwy 31: Climb and maintain **4000**. Climb hdg **315°** to **1300**, then direct to EBKEL, then track **315°** to VOGIG. Continue track **315°** for vectors to assigned route.

Note: Refer to Noise Abatement Procedures for additional requirements.

Communication Failure

On recognition of failure 10 minutes or less after take-off and in IFR weather conditions, proceed as follows:

1. Select transponder code 7600;
2. Upon reaching VOGIG, proceed on course;
3. Maintain last assigned altitude for 10 minutes after take-off, then climb to flight planned altitude.

Note: If communication failure occurs more than 10 minutes after take-off, comply with the appropriate procedure for communication failure enroute.

Source of Canadian Civil Aeronautical Data: © 2026 NAV CANADA All rights reserved