

Departure Route Description

All rwys: Maintain 8000 or as assigned.

Rwy 03 - ½: Climb hdg 032° to 2900, then climbing LEFT turn direct VESDO.

Rwy 21 - ½: Climb hdg 212° to 2900, then climbing RIGHT turn direct VESDO.

Communication Failure

On recognition of failure 10 minutes or less after take-off and in IFR weather conditions proceed as follows:

- 1. Select transponder code 7600;
- 2. Upon reaching VESDO proceed directly on course;
- 3. Maintain last assigned altitude until 10 minutes after take-off, then;
- 4. Climb to flight planned altitude.

Note: If communication failure occurs more than 10 minutes after take-off, comply with appropriate procedure for enroute communication failure.

Source of Canadian Civil Aeronautical Data: © 2026 NAV CANADA All rights reserved