

NOISE OPERATING RESTRICTIONS

Noise Operating Restrictions
and Noise Abatement Procedures

A. General

Pursuant to CAR 602.105 and CAR 602.106, Noise Operating Restrictions and Noise Abatement Procedures apply, at Toronto/Lester B. Pearson Intl Airport, to all IFR and VFR Aircraft, unless otherwise specified.

B. Noise Operating Restrictions
Restrictions:

1. Arrivals and departures of all aircraft are restricted as per the table below:

Aircraft	Restricted Hours – local time
Noise Certification or Type	Arrivals & Departures
All non-noise certificated jet aircraft	2000 – 0800
All ICAO annex 16, vol 1 chapter 2 & equivalent aircraft	0000 – 0700
All ICAO annex 16, vol 1 chapter 3 & equivalent aircraft (subject to paragraph 4 or 5)	0030 – 0630
All other aircraft (subject to paragraph 4 or 5)	0030 – 0630

2. Non-noise certificated jet powered aircraft are prohibited from departing on runways 05, 06L 06R, 15L, 15R and 33L.
3. Between 0000 and 0630 local time, departures are prohibited on runways 05, 06L, 06R, 15L & 15R and arrivals are prohibited on runways 24R, 24L, 23, 33R, 33L and 15R unless assigned by ATC.
4. All aircraft operating on a scheduled and repetitive basis are required to obtain an extension or an exemption to operate during the restricted hours. Submit requests for operating extensions on the day of operation to the GTAA with justification at 416-776-3480 or 1-800-267-SLOT (7568), (Fax 416-776-5552). For advance exemption requests or information, make submission in writing to the:
Manager
Slots Coordination
Greater Toronto Airports Authority
Toronto Pearson International Airport
P.O. Box 6031, Toronto AMF, Ontario L5P 1B2
(Fax 416-776-3483)
5. All other operators are required to obtain permission to operate during the restricted hours by contacting the GTAA on the day of operation at 416-776-3480 or 1-800-267-SLOT (7568), (Fax 416-776-5552).

Preferential runway assignment (0000 – 0630 local time)

Consistent with operational safety (i.e. wind, weather, runway conditions, approach aid availability, etc.), ATC shall assign runways in the following order of priority: Use as a pair.

Amended Preferential Runway System			
Preference	Arrivals	Departures	Notes
1	05 (06L/R)*	33R (33L)	Use as a Pair
2	15L (15R)	23 (24R/L)	Use as a Pair
* Alternate runways (in brackets) may be used when the corresponding preferential runway is not available			
Provision for Weather and Infrastructure Availability**			
Option	Arrivals	Departures	Notes
Northerly	33R (33L)	33R (33L)	Single Runway Operation
Southerly	15L (15R)	15L (15R)	Single Runway Operation
Westerly	23 (24R/L)	23 (24R/L)	Single Runway Operation
Easterly	05 (06L/R)	05 (06L/R)	Single Runway Operation
** Used as required when the first and second preference pairs are unavailable or not an appropriate choice			

Non-preferential runway requests must be approved by the GTAA Airport Duty Manager at 416-776-1104.

Source of Canadian Civil Aeronautical Data: © 2026 NAV CANADA All rights reserved